



### PACKAGE CONTENTS

- 1 - Leg Base Assembly
- 5 - Base Spreader Tubes
- 1 - Center Spreader Tube
- 2 - Net Posts
- 1 - 18' x 33" Net



### ASSEMBLING THE JUNIOR NET FRAME

- Step 1: Position the Leg Base Assemblies on the ground approximately 18' apart as shown above.
- Step 2: Insert the tapered (male) end of 1 Base Spreader Tube (male / female) into a Leg Base Assembly. Insert 2 more Base Spreader Tubes, each into the previous Base Spreader Tube as shown above.
- Step 3: Insert a Center Spreader Tube (male / male).
- Step 3: Insert the male end of the Center Spreader Tube into the female end of 1 Base Spreader Tube. Next, insert 1 Base Spreader Tube.
- Step 4: Insert the male end of the final Base Spreader Tube from Step 3 into the Leg Base Assembly as shown above.
- Step 5: Insert the Net Post into the top of each Leg Base Assembly.



### **INSTALLING THE NET**

Step 1: Unfold the Net along side of the assembled frame.

Step 2: Slide the Net Post Pockets over the upright Net Posts being sure the Net Headband is at the top.

Step 3: Route the Tension Strap around the Net Post and through the Locking Clip as shown above. Gently pull the end of the Tension Strap to tighten. Repeat this step at the other end of the Net. Adjust as necessary until the Net Headband is taught (caution: do not overtighten).

NOTE: To release the Net, lift the end of the Locking Clip while pulling the Net Headband away from the Net Post.

### **LIMITED ONE-YEAR WARRANTY**

GAMMA SPORTS ("GAMMA") warrants to the original purchaser that the Junior Net ("EQUIPMENT") purchased is free from defects in materials and workmanship for a period of ONE (1) year from the date of original purchase. Should any defects develop under normal use within the specified time period, GAMMA will, at its option, repair or replace the defective EQUIPMENT provided it is returned to GAMMA prepaid at the purchaser's expense. This warranty does not apply to any damage or defect caused by negligence, abuse, misuse, unauthorized alteration, shipping, handling, or wear and tear as a result of normal use.

GAMMA's obligation under this warranty is limited to replacement or repair of the defective EQUIPMENT, and no one is authorized to promise any other liability. GAMMA shall, in no event be liable for any incidental or consequential damages. This warranty gives you specific legal rights and you may also have other rights which vary from state-to-state.

To return defective EQUIPMENT, a return authorization (RA#) must be obtained from a GAMMA customer service representative by calling 1-800-333-0337. The RA# must be clearly marked on the outside of the shipping carton being returned. All returns must be shipped prepaid by the customer to GAMMA. Please retain the original shipping carton and packing materials for any future shipments. GAMMA will not be responsible for EQUIPMENT which is not returned in the original undamaged packaging.