

ASSEMBLING THE SCORE REPORTER

Step 1: Take one Clamp, place it around the net post, feed the open end of the Clamp through the Clamp Holes, then insert the Mounting Sleeve between the Clamp and net post and tighten to secure. Repeat for second Clamp.

Note: Be sure to position Clamps at least 1" from the bottom and top of the Mounting Sleeve.

Step 2: Insert Score Reporter Post into the Mounting Sleeve.

Step 3: Remove Score Cards from wrapper. Hang the red cards on one side and the black cards on the other. It does not matter which side is red or black.


USING THE SCORE REPORTER

Assign a color to each player or team (red or black).

When they change ends of the court, flip the appropriate Set Card indicating set score, then rotate the Score Reporter 180 degrees so that the color follows the players to their new ends of the court.

After one player or team has won a set, the appropriate color flag can be flipped down.

Upon completion of the match, the Score Reporter can be easily removed by lifting the Post from the Mounting Sleeve to avoid vandalism and/or exposure to the elements on outdoor courts.



LIMITED ONE-YEAR WARRANTY

GAMMA SPORTS ("GAMMA") warrants to the original purchaser that the Score Reporter ("EQUIPMENT") purchased is free from defects in materials and workmanship for a period of ONE (1) year from the date of original purchase. Should any defects develop under normal use within the specified time period, GAMMA will, at its option, repair or replace the defective EQUIPMENT provided it is returned to GAMMA prepaid at the purchaser's expense. This warranty does not apply to any damage or defect caused by negligence, abuse, misuse, unauthorized alteration, shipping, handling, or wear and tear as a result of normal use.

GAMMA's obligation under this warranty is limited to replacement or repair of the defective EQUIPMENT, and no one is authorized to promise any other liability. GAMMA shall, in no event be liable for any incidental or consequential damages. This warranty gives you specific legal rights and you may also have other rights which vary from state-to-state.

To return defective EQUIPMENT, a return authorization (RA#) must be obtained from a GAMMA customer service representative by calling 1-800-333-0337. The RA# must be clearly marked on the outside of the shipping carton being returned. All returns must be shipped prepaid by the customer to GAMMA. Please retain the original shipping carton and packing materials for any future shipments. GAMMA will not be responsible for EQUIPMENT which is not returned in the original undamaged packaging.