


PACKAGE CONTENTS

- 1 - Rebound Net Frame
- 1 - Rebound Net
- 1 - Rebound Net Carrying Case
- 2 - Metal Support Poles
- 1 - Support Pole Carrying Case



Important Precautions:

- Read ALL instructions before assembling.
- Use caution when assembling, net opens very fast.
- Never use where property or bystanders may be harmed.
- Should only be used for the purpose it was intended.
- Always store indoors in a dry place when not in use.



ASSEMBLING THE REBOUND NET




Step 1: In a wide open area, grasp the Rebound Net firmly and remove the elastic strap that holds the Rebound Net Frame in a folded position.




Step 2: Using both hands, toss the Rebound Net far away from your body into an open area. Use caution, the Rebound Net springs open quickly.



Step 3: Begin by assembling the two Metal Support Poles. Once assembled each pole will have a metal tip at either end.



Step 4: Take one pole and insert the pole tip through one of the metal grommets in the top of the net frame and cover the pole tip with the rubber cap. Insert the pole tip on the other end of the pole into the metal grommet of the frame on the ground and cover the tip with the rubber cap. Repeat this process on the other side of the net using the second pole.



Step 5: Tighten the crossing straps at the back of the Rebound Net by pulling on the loose strap ends near each buckle. This will stabilize the net when in use.

FOLDING THE REBOUND NET



Step 1: Carefully remove the rubber caps from the ends of the Support Poles and remove the pole tips from the net face and base, then fold the poles for storage.



Step 2: With the net standing on edge, grab the net using both hands. Put your foot on the bottom of the net and push down so the middle of the net bows away from you.



Step 3: Continue this motion until your hands are below your waist, then pull the top of the net toward your left side until the net is in a figure-8 shape.



Step 4: Fold the net straight down to the ground, laying the net flat into a figure-8 shape.



Step 5: Fold one of the circles formed in the figure-8 over on top of the other returning the Rebound Net to its original 3 1/2' folded circular form.



Step 6: Holding the folded Rebound Net firmly, secure the black elastic strap around the net to hold it so it will not spring open.

Step 7: Lay the Rebound Net Carrying Case flat on the ground, place the Rebound Net then the Support Pole Carrying Case inside the Rebound Net Carrying Case and zip the case closed.

LIMITED ONE-YEAR WARRANTY

GAMMA SPORTS ("GAMMA") warrants to the original purchaser that the Rebound Net ("EQUIPMENT") purchased is free from defects in materials and workmanship for a period of ONE (1) year from the date of original purchase. Should any defects develop under normal use within the specified time period, GAMMA will, at its option, repair or replace the defective EQUIPMENT provided it is returned to GAMMA prepaid at the purchaser's expense. This warranty does not apply to any damage or defect caused by negligence, abuse, misuse, unauthorized alteration, shipping, handling, or wear and tear as a result of normal use.

GAMMA's obligation under this warranty is limited to replacement or repair of the defective EQUIPMENT, and no one is authorized to promise any other liability. GAMMA shall, in no event be liable for any incidental or consequential damages. This warranty gives you specific legal rights and you may also have other rights which vary from state-to-state.

To return defective EQUIPMENT, a return authorization (RA#) must be obtained from a GAMMA customer service representative by calling 1-800-333-0337. The RA# must be clearly marked on the outside of the shipping carton being returned. All returns must be shipped prepaid by the customer to GAMMA. Please retain the original shipping carton and packing materials for any future shipments. GAMMA will not be responsible for EQUIPMENT which is not returned in the original undamaged packaging.