


PACKAGE CONTENTS

- 1 - Assembly Instructions Sheet
- 1 - Basket
- 2 - Legs
- 4 - Casters



SETUP

Step 1: Turn the cart upsidetdown so that the lid is resting on the ground.

Step 2: Unfold the legs and loosen the thumb knob so that the hinge rests between the leg and the thumb knob (Do this for both the front and rear legs).

Step 3: Tighten thumb knobs to secure leg braces to the legs and stand the Travel Cart upright for ball dispensing.


FOLDING LEGS FOR TRAVEL

Step 1: Close and secure the lid of the basket to prevent ball spillage (a lock, plastic ty-rap, or snapping the lid onto the s-hook on the side of the basket will work fine).


Step 2: Turn the cart upsidetdown so that the lid is resting on the ground.

Step 3: Fold up the legs and leg braces and secure them to the hinge brackets by tightening the knob into the hinge.

CASTER ASSEMBLY



- Step 1: Insert caster into the bottom of the cart leg.
- Step 2: Align leg holes with caster holes, insert bolts and attach nuts.
- Step 3: Tighten nuts/bolts to secure casters in place.



LIMITED ONE-YEAR WARRANTY

GAMMA SPORTS ("GAMMA") warrants to the original purchaser that the BALLHOPPER Cart ("EQUIPMENT") purchased is free from defects in materials and workmanship for a period of ONE (1) year from the date of original purchase. Should any defects develop under normal use within the specified time period, GAMMA will, at its option, repair or replace the defective EQUIPMENT provided it is returned to GAMMA prepaid at the purchaser's expense. This warranty does not apply to any damage or defect caused by negligence, abuse, misuse, unauthorized alteration, shipping, handling, or wear and tear as a result of normal use.

GAMMA's obligation under this warranty is limited to replacement or repair of the defective EQUIPMENT, and no one is authorized to promise any other liability. GAMMA shall, in no event be liable for any incidental or consequential damages. This warranty gives you specific legal rights and you may also have other rights which vary from state-to-state.

To return defective EQUIPMENT, a return authorization (RA#) must be obtained from a GAMMA customer service representative by calling 1-800-333-0337. The RA# must be clearly marked on the outside of the shipping carton being returned. All returns must be shipped prepaid by the customer to GAMMA. Please retain the original shipping carton and packing materials for any future shipments. GAMMA will not be responsible for EQUIPMENT which is not returned in the original undamaged packaging.